

Procedure for Drain MiniBooNE Horn RAW System.

- 1- Turn off RAW system at upstairs of MI-12B.
- 2- Move Argon bottle to tunnel.
- 3- Install nipple to strainer.
- 4- Install plastic hose to that nipple.
- 5- Install Rad. Pump, the other end of the plastic hose goes to the 55 gallons drum.
- 6- Turn on the pump.
- 7- Remove ¼" plug from supply line at wall, where is the thermocouple install.
- 8- Install gas hose.
- 9- Turn on gas to max. is 5 Psi.

- 10-Turn off four supply lines, let gas goes in only two supplies lines per time. Do that for all the supply lines for 15 min./two lines.

Parts Need:

- 1- Rad. Pump.
- 2- Extension core
- 3- Fitting for gas.